

Handleiding

Hodler Montreaux

1. Inleiding

Gefeliciteerd met uw aankoop van de Hodler Watch Montreaux!

Dit stijlvolle en duurzame horloge combineert elegantie met functionaliteit. In deze handleiding vindt u instructies over het instellen van de tijd en datum, onderhoudstips en garantie-informatie.



2. Specificaties

- Merk: Hodler Watches
- Model: Montreaux
- Gewicht: 135 gram
- Uurwerk (MOV'T): Quartz
- Glas: Glass crystal
- Kast: Zink
- Band: Roestvrij staal
- Gesp: Roestvrij staal
- Functie: Tijd, datum, 24 hour & stopwatch

3. Afmetingen

- Kastbreedte: 42 mm
- Kastdikte: 13 mm
- Bandbreedte: 18 mm
- Horlogelengte: 220 mm

4. Onderdelen van het horloge

- Uurwijzer
- Minutenwijzer
- Secondewijzer
- Stopwatch - in seconden en minuten
- Kroon (zijkant) - voor het instellen van de tijd en datum

5. Kleiner maken van horlogeband

Iedere pols is uniek daarom kan het zijn dat het horlogebandje nog niet helemaal perfect zit. Geen zorgen – met onze bijgeleverde tool (de horlogeversteller) kun je het bandje eenvoudig zelf aanpassen.

Wat heb je nodig?

- Je Hodler Watch
- De meegeleverde horloge versteller (prikker)
- Eventueel: een klein hamertje of een stevig voorwerp om het laatste stukje zachtjes mee vast te tikken

Stap-voor-stap uitleg

1. Bekijk de pinnetjes in het bandje
2. Als je goed kijkt, zie je in de schakels kleine pinnetjes.
3. Elk pinnetje heeft twee uiteindes:
 - Een smal uiteinde
 - Een breder uiteinde met een klein spleetje (de split)

Verwijder het pinnetje

1. Leg het horloge met de brede (gespleten) kant van het pinnetje van je af.
2. Zet de horloge versteller op het smalle uiteinde van het pinnetje.
3. Druk rustig maar stevig totdat het pinnetje eruit komt. Geef eventueel een tikje erop met een kleine hamer. Zorg dat de schakels recht op elkaar zitten.
4. Je kunt het laatste stukje eruit trekken met je vingers of een pincet.
5. Verkort het bandje
6. Haal het aantal schakels eruit dat nodig is voor een goede pasvorm van jouw pols. Let op: haal aan beide kanten evenveel schakels weg voor een mooie symmetrie!
7. Zet het bandje weer in elkaar
8. Steek het pinnetje weer terug in de openingen. Begin met de smalle kant.
9. Duw het pinnetje zo ver mogelijk met de hand erin.
10. Tik het laatste stukje zachtjes vast met een klein hamertje of een ander stevig voorwerp.

🔧 Bekijk ons uitlegfilmpje! We snappen dat het soms lastig is om dit voor je te zien. Daarom hebben we een handig filmpje gemaakt waarin we alles stap voor stap laten zien. **Klik hier** om het filmpje te bekijken.



6. Instellen van de tijd en datum

De kroon is het knopje aan de zijkant dat wordt gebruikt om de tijd en datum op het horloge in te stellen.



Tijd

Om de tijd van uw horloge in te stellen, trekt u eenvoudig de kroon naar de verste positie vanaf de basis van het horloge (twee klikken).

De middelste kroon

Datum

Om de datum van uw horloge aan te passen, trekt u de kroon met één klik naar achteren.

7. Gebruik van stopwatch

Het horloge heeft zowel een seconde als minuten stopwatch.



Bovenste drukknop

Start & stop van de stopwatch

Onderste drukknop

Resetten van de stopwatch

8. Onderhoud en verzorging

- Reiniging: Gebruik een zachte, droge doek om het horloge schoon te maken. Vermijd agressieve chemicaliën.
- Waterdichtheid: Het horloge is waterbestendig tot 30 meter, maar vermijd langdurige onderdompeling en warme douches om beschadiging te voorkomen.
- Opslag: Bewaar uw horloge op een droge en veilige plek, bij voorkeur in een horlogedoozje.

Uw Hodler Watch is ontworpen om waterbestendig te zijn bij dagelijks gebruik. Bij gebruik tijdens het zwemmen is het essentieel dat de kroon volledig is aangedraaid om binnendringend water te voorkomen. Let op: de Hodler is niet bestand tegen waterdamp. Draag het horloge daarom niet in de sauna, het stoombad of tijdens een hete douche.

De Hodler is een quartz-horloge en werkt op een batterij. Vermijd sterke temperatuurschommelingen en vochtige omgevingen om de levensduur van het uurwerk te optimaal te houden.

9. Probleemoplossing

Indien u problemen ondervindt met uw Hodler Watch Montreaux, neem dan contact op met onze klantenservice via info@hodlerproducts.com.





HODLER
WATCHES

Manual

Hodler Montreaux

1. Introduction

Congratulations on your purchase of the Hodler Watch Montreaux!

This stylish and durable watch combines elegance with functionality.

In this manual, you will find instructions on how to set the time and date, maintenance tips, and warranty information.



2. Specifications

- Brand: Hodler Watches
- Model: Montreaux
- Weight: 135 grams
- Movement: Quartz
- Glass: Glass crystal
- Case: Zinc
- Strap: Stainless steel
- Clasp: Stainless steel
- Functions: Time, date, 24-hour display & stopwatch

3. Dimensions

- Case width: 42 mm
- Case thickness: 13 mm
- Strap width: 18 mm
- Watch length: 220 mm

4. Watch Components

- Hour hand
- Minute hand
- Second hand
- Stopwatch – displays seconds and minutes
- Crown (side) – for setting the time and date

5. Adjusting the Size of Your Watch Band

Every wrist is unique, so the watch band might not fit perfectly right away. Don't worry — with our included tool (the watch adjuster), you can easily adjust the band yourself.

What do you need?

- Your Hodler Watch
- The included watch adjuster (pin pusher)
- Optional: a small hammer or sturdy object to gently tap the pin back in place

Step-by-step instructions

1. Locate the pins in the band
2. If you look closely, you'll see small pins in the links.
3. Each pin has two ends:
 - A narrow end
 - A wider end with a small slit (the split)

Remove the pin

1. Place the watch with the wider (split) end of the pin facing away from you.
2. Position the watch adjuster on the narrow end of the pin.
3. Gently but firmly press until the pin comes out. You may lightly tap it with a small hammer if needed. Make sure the links are aligned properly.
4. You can pull out the last bit of the pin with your fingers or tweezers.
5. Shorten the band
6. Remove the number of links needed for a comfortable fit around your wrist. Tip: For a symmetrical look, remove an equal number of links from both sides!
7. Reassemble the band
8. Insert the pin back through the holes. Start with the narrow end.
9. Push the pin in as far as you can by hand.
10. Gently tap the final part into place using a small hammer or other sturdy object.

🔧 Watch our tutorial video! We understand that this can be tricky to visualize. That's why we've created a helpful video showing each step in detail. **[Click here](#)** to watch the video.



6. Setting the Time and Date

The crown is the small button on the side of the watch used to set the time and date.



Time

To set the time on your watch, simply pull the crown out to the furthest position from the base of the watch (two clicks).

The middle crown

Date

To adjust the date on your watch, pull the crown out one click from the base.

7. Using the Stopwatch

The watch features a stopwatch that measures both seconds and minutes.



Top Button

Start and stops the stopwatch

Bottom Button

Resets the stopwatch

8. Maintenance and Care

- Cleaning: Use a soft, dry cloth to clean the watch. Avoid harsh chemicals.
- Water Resistance: The watch is water-resistant up to 30 meters, but avoid prolonged submersion and hot showers to prevent damage.
- Storage: Store your watch in a dry and safe place, preferably in a watch box.

Your Hodler Watch is designed to be water-resistant for everyday use. When wearing it while swimming, it is essential that the crown is fully tightened to prevent water from entering. Please note: the Hodler is not resistant to water vapor. Therefore, do not wear the watch in the sauna, steam room, or during a hot shower.

The Hodler is a quartz watch and operates on a battery. To ensure the longevity of the movement, avoid extreme temperature fluctuations and humid environments.

9. Troubleshooting

If you experience any issues with your Hodler Watch Montreaux please contact our customer service at info@hodlerproducts.com.



Warranty Terms

1. Warranty period

The watch comes with a **1-year** warranty.

2. What is covered by the warranty?

- Manufacturing defects in the movement (e.g., the watch does not run properly despite correct use).
- Defects in the hands, dial, or quartz/mechanical movement.
- Battery issues if the battery runs out within a few months (3) of purchase.

3. What is not covered by the warranty?

- Damage due to personal use, such as scratches, impacts, or broken glass.
- Wear and tear of the strap, clasp, or case from normal use.
- Water damage if the watch is not properly sealed or if water resistance limits have been exceeded.
- Battery replacement, unless explicitly stated.
- Repairs or modifications by unauthorized watchmakers.

4. How does the warranty work?

- You must present a proof of purchase or warranty certificate.
- Repairs are typically carried out by an authorized service center.

Please visit our website or contact customer service for more details regarding the warranty policy.

This watch is covered by the standard warranty terms of Hodler Watches.

We hope you enjoy your Hodler Watch Montreaux!

